PAGE: 1

PRINT DATE: 08/27/93

FAILURE MODES EFFECTS ANALYSIS (FMEA) - CRITICAL HARDWARE

NUMBER: 06-1C-0122-X

SUBSYSTEM NAME: ARS - ARPCS

REVISION:

ø

08/26/93

PART NAME

**VENDOR NAME** 

PART NUMBER VENDOR NUMBER

LRU

: EMERGENCY 02 CONTROL PANEL

MC250-0002-0120

CARLETON TECHNOLOGIES

2735-0001

**SRU** 

VALVE, RELIEF & REG, EM 02

1-4-00-58-15

# PART DATA

QUANTITY OF LIKE ITEMS: 2 ONE PER FLOW PATH TWO PER PANEL

FUNCTION:

RELIEF VALVE, EMERGENCY 02 REGULATOR

PROVIDE OVERPRESSURE RELIEF CAPABILITY DOWN STREAM OF EMERGENCY OXYGEN REGULATOR. RELIEF PRESSURE IS 245 PSIG. THIS VALVE IS INTEGRAL TO THE ON/OFF VALVE AND THE REGULATOR.

850230C ATTACHMENT -Page 63 of 197

# SHUTTLE CRITICAL ITEMS LIST - ORBITER

SUBSYSTEM :ATMOSPHERIC REVIT. FMEA NO 06-10 -0122 -2 REV:08/10

ASSEMBLY : EMERGENCY 02 CONTROL PNL

CRIT. FUNC: 1g

:MC250-0002-0120 P/N RI

CRIT. HDW:

P/N VENDOR: 1-4-00-58-15 CARLETON

102 103 104

QUANTITY :2

EFFECTIVITY: Х X

ONE FER REGULATOR

PHASE(S): PL X LO X OO X DO X LS X

REDUNDANCY SCREEN: A-PASS B-N/A

VEHICLE

C-PASS

PREPARED BY: DES M. PRICE WAR

APPROVED BY // The hand bear to the REL H. L. STEISSLINGER) BREL JOHN GE S. MOR APPROVED BY MASA REL QE (

ITEM:

RELIEF VALVE, EMERGENCY 02 REGULATOR

### FUNCTION:

PROVIDE OVERPRESSURE RELIEF CAPABILITY DOWN STREAM OF EMERGENCY OXYGE: REGULATOR. RILIEF PRESSURE IS 245 PSIG. THIS VALVE IS INTIGRAL TO THE ON/OFF VALVE AND THE REGULATOR.

PAILURE MODE: CLOSED

CAUSE(5):

MECHANICAL SHOCK, VIBRATION, CONTAMINATION, CORROSION

### EFFECT(S) OK:

- (A) SUBSYSTEM (B) INTERFACES (C) MISSION (D) CREW/VEHICLE
- (A) LOSS OF OVERPRESSURE PROTECTION AGAINST & FAILED REGULATOR. PANEL OUTLET PRESSURE WOULD RISE TO INLET PRESSURE AND IMPLEMENTATION OF CORRECTING ACTION (C/A) WOULD CLOSE ONE OF TWO REDUNDANT OF FLOW PATHS.
- (B) LES BREATHING STATIONS INTERFACE WOULD GET PRESSURE UP TO 1050 PSIG.
- (C) ABORT DECISION.
- (D) NO EFFECT. LES EQUIPMENT CONTAINS RELIEF VALVES AND WHEN PUT INTO USE OVERPRESSURE WOULD RELIEVE INTO CABIN RESULTING IN PPO2 INCREASE UNTIL C/A IS IMPLEMENTED.
- (E) FUNCTIONAL CRITICALITY EFFECT SUBSIQUENT FAILURE OF REDUNDANT SYSTEM RESULTS IN LOSS OF OXYGEN SUPPLY TO LES BREATHING STATIONS. SCREEN B IS M/A BY DEFINITION OF RELIEF VALVES AS STANDBY REDUNDANCY.

## SHUTTLE CRITICAL ITEMS LIST - ORBITER

SUBSYSTEM : ATMOSPHERIC REVIT. FMEA NO 06-1C -0122 -2 REV:08/10/88

DISPOSITION & RATIONALE:

(A) DESIGN (B) TEST (C) INSPECTION (D) FAILURE HISTORY (E) OPERATIONAL USE

### (A) DESIGN

THE VALVE BODY IS MADE OF ALUMINUM ALLOY 6061. THE REGULATOR IS AN INLET PRESSURE COMPENSATED, SPRING-REFERENCED TYPE EMPLOYING A 17-7 PM CONDITION C CRES DIAPHRAGM AS A SENSING ELEMENT AND DYNAMIC SEAL. 17-7 PM IS PRECIPITATION HARDENED CORROSION RESISTANT STIEL WHICH HAS A HIGH STRENGTH TO WEIGHT RATIO. THE DIAPHRAGM SEALS WHICH ARE MADE OF SILASTIC 675 SILICONE RUBBER HAVE EXCELLENT RESISTANCE TO OXYGEN, OUTGASSING, AND FATIGUE. THEY ELIMINATE THE FRICTION—AND WEAR ASSOCIATED WITH PISTON TYPE SEALS. THE HELICAL/BELLEVILLE SPRING COMBINATION WHICH IS MADE OF 17-7 PH CRES PROVIDES REGULATION AND ASSURES A CLOSE TOLERANCE OPERATION OVER A WIDE FLOW RANGE. THE POPPET WHICH IS ALSO MADE OF 17-7 PH CRES WORKS AGAINST A POLYTMIDE VESPEL SP-1 SEAT WHICH ASSURES A LEAK FREE OPERATION. THE INLET AND OUTLET PORTS ARE FILTER PROTECTED TO 25 MICRONS.

### (B) TEST

ACCEPTANCE TEST - PROOF TEST AT 1875 +/- 25 PSIG FOR A MINIMUM OF 3 MINUTES. LEAK TESTED AT INLET PRESSURE 885 +/- 25 PSIG AND OUTLET PRESSURE 125 PSIG; 0.3 SCCM MAX LEAKAGE. INTERNAL LEAKAGE TEST PERFORMED AT THE SAME PRESSURE; 0.2 SCCM MAX LEAKAGE. RELIEF VALVE OPERATIONAL TEST AT A CRACKING PRESSURE OF 245 PSIG MAX AND A RESEAT PRESSURE OF 215 PSIG MINIMUM.

QUALIFICATION TEST - LIFE CYCLE TESTING - 1000 CYCLES AT 875 +/- 25 PSIG. BURST PRESSURE IS 2500 PSIG. SUBJECTED TO THE FOLLOWING AS PART OF THE EMERGENCY O2 CONTROL PANEL. DESIGN SHOCK - THE UNIT WAS SUBJECTED TO 3 SHOCKS OF A 20 G PEAK ACCELERATION PULSE APPROXIMATELY A SAWTOOTH AND HAVING A TOTAL DURATION OF 11 MILLISECONDS. THIS PULSE WAS APPLIED IN BOTH DIRECTIONS OF THE THREE PRINCIPLE AXES FOR A TOTAL OF 18 SHOCKS. RANDOM VIBRATION SPECTRUM ENVELOPE - 20 TO 150 HZ INCREASING AT 6 DB, OCTAVE TO 0.03 G\*\*2/HZ AT 150 HZ. CONSTANT AT 0.03 G\*\*2/HZ FROM 150 TO 1000 HZ, DECREASING AT 6 DB/OCTAVE FROM 1000 TO 2000 HZ FOR 48 MINUTES PER AXIS FOR THREE ORTHOGONAL AXES. ATP TO VERIFY LEAKAGE IS PERFORMED AFTER SHOCK AND VIBRATION TESTING.

IN-VEHICLE TESTING - RELIEF VALVE CRACK, RESEAT AND RESEAT LEAKAGE (10 SCCM MAX) TEST IS PERFORMED.

OMRSD - RELIEF VALVE CRACK, RESEAT AND RESEAT LEAKAGE (10 SCCM MAX) TEST IS PERFORMED BEFORE THE FIRST REFLIGHT OF EACH ORBITER AND AT INTERVALS OF FIVE FLIGHTS.

### (C) INSPECTION

RECEIVING INSPECTION

RAW MATERIAL VERIFIED BY INSPECTION FOR MATERIAL AND PROCESS CERTIFICATION.

CONTAMINATION CONTROL CORROSION PROTECTION PROVISIONS AND CONTAMINATION CONTROL PLAN ARE

S50230C ATTACHMENT -Page 65 of 197

# SHUTTLE CRITICAL ITEMS LIST - ORBITER

SUBSYSTEM : ATMOSPHERIC REVIT. FMEA NO 06-1C -0122 -2 REV:08/10/

VERIFIED BY INSPECTION. CLEANLINESS LEVEL 200A PER MA0110-301 VERIFIED BY INSPECTION.

### ASSEMBLY/INSTALLATION

BELLEVILLE SPRING FORCES AND TORQUES ARE VERIFIED. DIMENSIONAL CHECKS ARE PERFORMED BY INSPECTION. MIPS FOR CONCENTRICITY AND PERPENDICULARITY. VISUAL INSPECTION USING 10X MAGNIFICATION ON SEAL RING VERIFIED BY INSPECTION.

### NONDESTRUCTIVE EVALUATION

BRAZING, WELDING, X-RAYS AND PENETRANT INSPECTIONS ARE VERIFIED BY INSPECTION.

## CRITICAL PROCESSES

HEAT TREAT AND PARTS PASSIVATION AND ANODIZING ARE VERIFIED BY INSPECTION. LUBRICANT APPLICATION ON SEAL RING VERIFIED BY INSPECTION. POTTING VISUALLY VERIFIED BY INSPECTION. SOLDERING VERIFIED BY INSPECTION.

#### TESTING

ATP VERIFIED BY INSPECTION.

g-----

# HANDLING/PACKAGING

HANDLING, PACKAGING, STORAGE AND SHIPPING PROCEDURES ARE VERIFIED BY INSPECTION.

### (D) FAILURE HISTORY

NO FAILURE HISTORY APPLICABLE TO CLOSED FAILURE MODE. THE RELIEF VALUE HAS SUCCESSFULLY BEEN USED THROUGH THE SHUTTLE PROGRAM CONSIDERING THIS FAILURE MODE.

(E) OPERATIONAL USE TBS.