

DISPOSABLE DRR  
DISTRIBUTION POINT  
DRR IDENTIFICATION  
DRR Part Number: 10100-00045-01

DRR CRITICAL ITEMS

Rev. 9-7-3

ITEM	DRR	DRR IDENTIFICATION	CODE	FAILURE MODE AND CAUSE	EXTENDED EFFECT ON DRR DRRA	CRITERIA FOR ACCEPTANCE
5.2.1a	MINNIS ASSISTANT 10100-00045-01	2/10		<b>Failure Mode:</b> Separation of straps or Velcro.  <b>Note:</b> Breaks stitching Material failure	DRR becomes inoperative with possible urine leakage into DR	<ul style="list-style-type: none"><li>1) Design: Strap and fastener materials and stitching were selected to provide the strength and durability to secure the DRRA to the DRR crewman test.</li><li>2) Acceptance: Visual inspection is performed at PRR during which straps, fastener tapes (Velcro) and stitching is examined.</li><li>3) Certification: The DRRA was certified by analysis based on review of drawing 10100-00045-01.</li><li>4) Disposal: Used DRRA's are disposed of. Used DRR's are visually inspected at PRR.</li><li>5) Inspection:<ul style="list-style-type: none"><li>a) Manufacturing: In-process inspection covering all manufacturing operations, stitching, and verification of materials is performed.</li><li>b) Turnaround: Used DRRA's undergo visual inspection at PRR.</li></ul></li><li>6) Failure History: None</li><li>7) Operational Use:<ul style="list-style-type: none"><li>a) Effects of failure: Removal of DRR (aborts) may be necessary.</li><li>b) Crew Action: Determine extent of problems; continue DRR or return to orbitier.</li><li>c) Crew Training: None</li><li>d) Mission Constraints: None</li><li>e) In-Flight Checkout: Visually inspect security of straps and Velcro.</li></ul></li></ul>