

DISPOSABLE URINE
COLLECTION DEVICE

LIC CRAFTS LISTS

TYPE AND SOURCE: 10100-URINE-L

STATUS:

VER. 10

REV. 00

DATE: 9-7-87

Ref ID	NAME, SIC AND ADDRESS OF MANUFACTURER	CRAFT	Failure mode and cause	Failure effect on CRAFT	MATERIALS FOR REPAIR/REPLACEMENT	
					Ref ID#	Ref ID#
10100	VALVE FLAPPER 10100-URINE-L	2/10	<u>Failure Mode:</u> Leakage between flapper and seat. <u>Cause:</u> Foreign matter between flapper and seat.	Leakage from bag into cuff and possible leakage into bag. Leakage into orbiter when donning DODD.	1) Design: The valve flapper used with the valve seat is a one way valve allowing air to flow into the bag and preventing flow back out. The flapper is made from silicone rubber to provide the necessary sealing capability. 2) Test: a) Acceptance: The valve flapper is leak tested in the DODD during PQA (at 2 psig) and at PIR (at 2 psig). b) Certification: The DODD was certified by analysis based on review of drawing MMOD-10000-01. c) Turnaround: Used DODD's are disposed of. Unused DODD's are leak tested at PIR at 2 psig, during which a defective valve would be discovered. d) Inspection: a) Manufacturing: The valve flapper is a vendor item and undergoes a 100% visual inspection upon receipt. b) Storage: Unused DODD's undergo visual inspection at PIR. c) Failure History: None. d) Operational Use: a) Effects of failure: Activation of TCU (alarm) may be necessary. b) Emergency Action: No normal extent of problem; continue EVA or return to orbiter. c) Crew Briefing: Orientation includes discussion of possible failure, effect on press, possible need to abort. d) Flight constraints: None. e) In-flight checkout: None.	