

CRITICAL ITEMS LIST

REFERENCE DESIGNATOR: HET-1
 NAME / QUANTITY: Interface Adapter Assy.
 DRAWING REFERENCE: 6.32, 33, 34

PROJECT: HST
 LRU NAME / QUANTITY: Interface Adapter Assy.
 LRU PART NUMBER: See List In Section 2.0 of This Document

PAGE 1 OF 5
 SUBSYSTEM: TOOLS
 EFFECTIVITY: ALL ORINTERS

FAILURE MODE NUMBER	CRITICALITY	FAILURE EFFECT	RETENTION RATIONALE
HST-HET-1-1	2/2		
FUNCTION The interface adapter connects to a bayonet receptacle on the mini-work station and the manipulator tool restraint (MFR) work stanchion. The HST power tool and McTether and ratchet caddies have interface adapter assy. attached to them.		END ITEM Cannot detach HST tool(s) from the MFR work stanchion.	DESIGN 1. Design Feature to Minimize the Chance of the Failure Mode A. Design All HST tools were designed to an ultimate structural safety factor of 1.4.
FAILURE MODE AND CAUSE MODE Cannot disengage an interface adapter assy. from the bayonet receptacle on the MFR work stanchion		MISSION Unable to use the MFR on subsequent EVAs. Unable to properly stow the MFR.	B. Tolerances Sufficient tolerances will be used in the Interface adapter design to prevent jamming by expansion and contraction of material due to temperature extremes or on-orbit use.
CAUSE(S) 1.) Contamination. 2.) Binding.		CREW / VEHICLE None.	C. Materials - Major Components 1. Bracket: Al 6061-T651 2. Pin: CRES 304 S/S II. Testing and Analysis A. Acceptance Testing 1. PDA A full pre-delivery acceptance (PDA) test will be performed on the HST tools before they are delivered to JSC for the beginning of the certification process. The PDA will verify that the Interface adapter is built within tolerances and that the assembly is clean
REDUNDANCY SCREENS	REMAINING PATHS		2. Vibration The flight tool box will be exposed to acceptance vibration loads while all tools are in their flight stowage location. The test will verify that the Interface adapters will be free of manufacturing defects and identify any tolerance problems.
A - N/A B - N/A C - N/A	1.) None.		
MISSION PHASE	CORRECTIVE ACTION TIMES		
	TIME TO EFFECT	TIME TO CORRECT	
EVA	Hours	Minutes	

CRITICAL ITEMS LIST

REFERENCE DESIGNATOR: HET-1
 NAME / QUANTITY: Interface Adapter Assy.
 DRAWING REFERENCE: b-32, 33, 34

PROJECT: HST
 LRU NAME / QUANTITY: Interface Adapter Assy.
 LRU PART NUMBER: See List in Section 2.6 of This Document

PAGE 2 OF 5
 SUBSYSTEM: TOOLS
 EFFECTIVITY: ALL ORBITERS

FAILURE MODE NUMBER HST-HET-1-1		CRITICALITY 2/2	FAILURE EFFECT	RETENTION RATIONALE																																											
FUNCTION		END ITEM Cannot detach HST tool(s) from the MFR work stanchion. The HST power tool and McTether and ratchet caddies have Interface adapter assy. attached to them.	MISSION Unable to use the MFR on subsequent EVAs. Unable to properly stow the MFR.	DESIGN A. Acceptance Testing (continued) The following vibration levels are per SMD memo ES42-92-134: <table> <thead> <tr> <th>Frequency (Hz)</th> <th>Slope (dB/oct.)</th> <th>Constant Level G²/Hz</th> <th>Overall Gms</th> </tr> </thead> <tbody> <tr> <td>20-80</td> <td>+3.0</td> <td>.04</td> <td>6.1</td> </tr> <tr> <td>80-350</td> <td>-3.0</td> <td></td> <td></td> </tr> <tr> <td>350-2000</td> <td></td> <td></td> <td></td> </tr> <tr> <td>20-45</td> <td>+10.0</td> <td>.06</td> <td>7.7</td> </tr> <tr> <td>45-600</td> <td></td> <td></td> <td></td> </tr> <tr> <td>600-2000</td> <td>-6.0</td> <td></td> <td></td> </tr> <tr> <td>20-70</td> <td>+4.0</td> <td>.05</td> <td>7.0</td> </tr> <tr> <td>70-600</td> <td></td> <td></td> <td></td> </tr> <tr> <td>600-2000</td> <td>-6.0</td> <td></td> <td></td> </tr> </tbody> </table> B. Certification Testing 1. Thermal Vacuum The HST tools will be exposed to a cold temperature (-90°F) vacuum (1×10^{-5} torr) environment. Although the MFR will not be a part of this test, similar bayonet receptacles will be used to check the tolerances of the Interface adapter. Dimensional measurements will be taken of the flight MFR bayonet receptacles and an analysis will be performed to verify that no tolerance problems exist at the cold temperature.				Frequency (Hz)	Slope (dB/oct.)	Constant Level G ² /Hz	Overall Gms	20-80	+3.0	.04	6.1	80-350	-3.0			350-2000				20-45	+10.0	.06	7.7	45-600				600-2000	-6.0			20-70	+4.0	.05	7.0	70-600				600-2000	-6.0		
Frequency (Hz)	Slope (dB/oct.)	Constant Level G ² /Hz	Overall Gms																																												
20-80	+3.0	.04	6.1																																												
80-350	-3.0																																														
350-2000																																															
20-45	+10.0	.06	7.7																																												
45-600																																															
600-2000	-6.0																																														
20-70	+4.0	.05	7.0																																												
70-600																																															
600-2000	-6.0																																														
FAILURE MODE AND CAUSE																																															
MODE																																															
Cannot disengage an interface adapter assy from the MFR work stanchion.																																															
CAUSE(S)		1.) Contamination. 2.) Binding.	CREW / VEHICLE None.																																												
REDUNDANCY SCREENS																																															
A - N/A B - N/A C - N/A																																															
		REMAINING PATHS 1.) None.	INTERFACE MWS work stanchion.																																												
MISSION PHASE		CORRECTIVE ACTION TIMES																																													
		TIME TO EFFECT	TIME TO CORRECT																																												
EVA		Hours	Minutes																																												

CRITICAL ITEMS LIST

REFERENCE DESIGNATOR: HET-1
 NAME / QUANTITY: Interface Adapter Assy.
 DRAWING REFERENCE: 6.22, 33, 34

PROJECT: HST
 LRU NAME / QUANTITY: Interface Adapter Assy.
 LRU PART NUMBER: See List in Section 2.0 of This Document

PAGE 3 OF 5
 SUBSYSTEM: TOOLS
 EFFECTIVITY: ALL ORBITERS

FAILURE MODE NUMBER	CRITICALITY	FAILURE EFFECT	RETENTION RATIONALE
HST-HET-1-1	2/2		
FUNCTION The Interface adapter connects to a bayonet receptacle on the mini-work station and the manipulator tool restraint (MFR) work stanchion. The HST power tool and McTether and ratchet caddies have interface adapter assy. attached to them.		END-ITEM Cannot detach HST tool(s) from the MFR work stanchion.	DESIGN B. <u>Certification Testing (continued)</u> 2. Functionals The HST tools will be functionally operated prior to and immediately after all certification test to verify that the test environment does not degrade the hardware performance. Attach/disconnect operations with the MFR will be part of these tests.
FAILURE MODE AND CAUSE MODE Cannot disengage an interface adapter assy. from the MFR work stanchion. CAUSE(S) 1.) Contamination. 2.) Blinding.		MISSION Unable to use the MFR on subsequent EVAs. Unable to properly stow the MFR.	C. <u>Certification Analysis</u> All interface adapter assembly will be analyzed to the following induced environments to verify that the assembly can withstand the environment levels: I. Requirements Source Applicability a. <u>Shock</u> - Functional NSTS-07700 VOL. XIV II stowed in box b. <u>Vibration (ER Levels)</u> - Acoustics NSTS-07700 VOL. XIV II stowed in box c. <u>Structures</u> - Util. (n = 2 0) NSTS-07700 VOL. XIV Applicable to all - Fracture NSTS-07700 VOL. XIV Applicable to all d. <u>Acceleration</u> - Flight MF0004-014D II stowed in box - Crash MIL-STD-810, Meth. 516, Proced I II stowed in box e. <u>Temperature</u> - Hot (+250°F) HST S/AO (10181-10081A) Applicable to all - Cold (-90°F) HST S/AO (10181-10081A) Applicable to all
REDUNDANCY SCREENS A - N/A B - N/A C - N/A	REMAINING PATHS 1.) None.	CREW / VEHICLE None.	
MISSION PHASE	CORRECTIVE ACTION TIMES		
	TIME TO EFFECT	TIME TO CORRECT	
EVA	Hours	Minutes	

CRITICAL ITEMS LIST

PAGE 4 OF 5

SUBSYSTEM: TOOLS

EFFECTIVITY: ALL ORBITERS

REFERENCE DESIGNATOR: HET-1
 NAME / QUANTITY: Interface Adapter Assy.
 DRAWING REFERENCE: 6.32, 30, 34

PROJECT: HST
 LRU NAME / QUANTITY: Interface Adapter Assy.
 LRU PART NUMBER: See List in Section 2.0 of this Document

FAILURE MODE NUMBER HST-HET-1-1	CRITICALITY 2/2	FAILURE EFFECT	RETENTION RATIONALE
FUNCTION	The interface adapter connects to a bayonet receptacle on the mid-work station and the manipulator tool restraint (MFR) work stanchion. The HST power tool and McTether and ratchet caddies have interface adapter assy. attached to them.	END ITEM Cannot detach HST tool(s) from the MFR work stanchion.	DESIGN MI. Inspection A. Manufacturing 1. The interface adapter assemblies will be inspected prior to build up for conformance to their applicable drawings. 2. All fracture critical piece parts will be inspected as described on their applicable drawings. B. Assembly 1. Tools will be cleaned and inspected to the levels described in JSC 5322B. Once cleaned, the tool will be bagged to prevent any contamination from entering the tool. All tools will be stored in their appropriate location in the box and the box will be sealed prior to shipment to the KSC. C. Testing 1. The hardware will be fully inspected for any signs of galling as a part of the pre/post functional tests performed prior to and immediately after all major certification and acceptance testing. 2. All HST tools with interface adapters will be fit checked with the flight MFR
FAILURE MODE AND CAUSE	MODE Cannot disengage an interface adapter assy. from the MFR work stanchion. CAUSES 1.) Contamination. 2.) Binding.	MISSION Unable to use the MFR on subsequent EVAs. Unable to properly stow the MFR.	
REDUNDANCY SCREENS	REMAINING PATHS 1.) None.	CREW / VEHICLE None.	
MISSION PHASE	CORRECTIVE ACTION TIMES TIME TO EFFECT TIME TO CORRECT	INTERFACE MWS work stanchion.	
EVA	Hours Minutes		

CRITICAL ITEMS LIST

REFERENCE DESIGNATOR: HET-1
 NAME / QUANTITY: Interface Adapter Assy.
 DRAWING REFERENCE: b32, 52,34

PROJECT: HST
 LRU NAME / QUANTITY: Interface Adapter Assy.
 LRU PART NUMBER: See List in Section 2.9 of This Document

PAGE 5 OF 5
 SUBSYSTEM: TOOLS
 EFFECTIVITY: ALL CIRUITERS

FAILURE MODE NUMBER HST-HET-1-1	CRITICALITY 2/2	FAILURE EFFECT	RETENTION RATIONALE
FUNCTION			
The interface adapter connects to a bayonet receptacle on the mini-work station and the manipulator foot restraint (MFR) work stanchion. The HST power tool and McTether and ratchet caddies have interface adapter assy. attached to them.		EMD ITEM Cannot detach HST tool (s) from the MFR work stanchion.	DESIGN IV. Failure History A. There have been no failures associated with the interface adapter to the MFR work stanchion.
FAILURE MODE AND CAUSE			
MODE Cannot disengage an interface adapter assy. from the MFR work stanchion. CAUSE(S) 1.) Contamination. 2.) Binding.			MISSION Unable to stow the MFR on subsequent EVAs. Unable to properly stow the MFR.
			CREW / VEHICLE None.
			INTERFACE MWS work stanchion.
REDUNDANCY SCREENS		REMAINING PATHS	
A - N/A		1.) None.	
B - N/A			
C - N/A			
MISSION PHASE		CORRECTIVE ACTION TIMES	
		TIME TO EFFECT	TIME TO CORRECT
EVA	Hours	Minutes	

FMEA /CIL for the HST EVA Tools, JSC-37687

